Philips
CD Soundmachine

MP3

AZ1845

Enjoy great sound wherever you go

Want to free your favorite digital tunes from your portable music player and enjoy them all in powerful sound? With Philips CD Soundmachine AZ1845's USB Direct, you can! Plus, it features one-touch MP3 digital recording - no PC required.

Easy to use
- One-touch MP3 digital recording - no computer needed
- MP3 link for portable music playback
- Stereo headphone socket

Multisource music enjoyment
- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM/MW stereo tuner

Powerful sound you can hear and feel
- Bass Reflex Speakers for a deep, powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- 4" full range speakers for powerful sound
- 2x1W RMS total output power

PHILIPS
sense and simplicity

CD Soundmachine
MP3

AZ1845/55

Specifications

Audio Playback
- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Connectivity
- USB: USB host
- Headphone: 3.5 mm
- 3.5mm stereo line in: MP3 LINK

Tuner/Reception/Transmission
- Antenna: FM Antenna
- Tuner Bands: FM, MW

Sound
- Output power (RMS): 2X1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: rotary
- Loudspeaker types: Bass Reflex Speaker System

Loudspeakers
- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Convenience
- Display Digits: 3
- Display Type: LCD

Accessories
- Included Accessories: AC Power Cord, Warranty certificate, 3.5mm stereo line in cable, Flat pin adaptor
- User Manual: Spanish and Brazilian Portuguese

Dimensions
- Product dimensions (W x H x D): 420 x 168 x 240 mm
- Packaging dimensions (W x H x D): 457 x 283 x 210 mm
- Weight: 2.8 kg
- Weight incl. Packaging: 3.8 kg

Power
- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power: 110 - 127V and 220 - 240V AC voltage selectable
- Number of batteries: 6

Audio Recording
- Recording Media: USB device
- USB recording modes: Instant record, Programmed tracks, Single disc, Single track
- USB recording sources: CD

Product highlights

One-touch MP3 recording
Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch operation and no computer needed.

Bass Reflex Speakers
Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

USB Direct-MP3/WMA
With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the device.

MP3 link for portable music
MP3 link allows direct playback of MP3 files from your portable media player on your audio system. Simply connect your portable media player to the built-in MP3 link jack on an audio system and enjoy your MP3 music in superior sound quality.

Issue date 2008-07-03
Version: 4.0.6
12 NC: 8670 000 40377
EAN: 87 12581 42883 9

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Avoid extensive use of the set at a volume higher than 85 decibels because this may damage your hearing.